


Microchannel Evaporators

HEAT EXCHANGERS FOR EVAPORATOR APPLICATIONS

- ▶ DESIGN AND SPECIFICATIONS
- ▶ INSTALLATION GUIDELINES
- ▶ MAINTENANCE



TECHNICAL MANUAL
ENGLISH



HFC-BASED
REFRIGERANTS



HFO-BASED
REFRIGERANTS



NATURAL
REFRIGERANTS

CUSTOMER SERVICES

Maintenance and Warranty

As standard, Kaltra guarantees heat exchangers for a period of 24 months uncoated and 60 months e-coated, variations tailored to suit product and application are also available; please contact Kaltra for full terms and details.

For a free quotation contact Kaltra or your local sales engineer. All Kaltra products are designed in accordance with European and international standards and norms.



CAUTION

Warranty cover is not a substitute for maintenance. Warranty cover is conditional to maintenance being carried out in accordance with the recommendations provided during the warranty period. Failure to have the maintenance procedures carried out will invalidate the warranty and any liabilities by Kaltra.

In addition to warranty services, a 24 hour, 7 days a week on-call service is available throughout the year to EU sites. This service will enable customers to contact a duty engineer outside normal working hours and receive assistance over the telephone or per email. The duty engineer can, if necessary, attend site. Full details will be forwarded on acceptance of the maintenance agreement.

Service Contacts

For further assistance, please e-mail: support@kaltra.de or telephone:

Sales enquiries:	+49 (0) 911 715 320 21	sales@kaltra.de
24/7 support hotline:	+49 (0) 151 418 586 90	support@kaltra.de
Information:	+49 (0) 089 943 998 66	info@kaltra.de
Delivery:	+49 (0) 911 715 320 21	delivery@kaltra.de
Spares:	+49 (0) 911 715 320 21	spares@kaltra.de

Kaltra endeavours to ensure that the information in this document is correct and fairly stated, but none of the statements are to be relied upon as a statement or representation of fact. Kaltra does not accept liability for any error or omission, or for any reliance placed on the information contained in this document. The development of Kaltra products and services is continuous and the information in this document may not be up to date. It is important to check the current position with Kaltra at the address stated. This document is not part of a contract or licence unless expressly agreed.

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, for any purpose other than the purchaser's personal use, without the express written permission of Kaltra.

© 2020 Kaltra GmbH. All rights reserved. Printed in Germany.

SAFETY

The information contained in this manual is critical to correct installation and maintenance of heat exchangers and should be read by all persons responsible for the procedures mentioned above.

Heat exchangers have been designed and manufactured to meet international safety standards, but care must be taken if you are to obtain the best results.



CAUTION

Installation and maintenance work on heat exchangers should be undertaken by competent and trained personnel in accordance with local relevant standards and codes of practice.

Improperly installed, adjusted or altered equipment by an unqualified person could result in death or severe injury. When working on the equipment, observe all precautions in the literature and on the tags, stickers, and labels that are attached to the equipment.

Personal Protective Equipment and Handling

Kaltra recommends that personal protective equipment is used while installing and servicing heat exchangers. Some operations, when servicing heat exchangers, may require additional assistance with regard to manual handling. This requirement is down to the discretion of the engineer. Remember, do not perform a lift that exceeds your ability.

Refrigerant Warning

When working with or around hazardous chemicals, including refrigerants, always refer to the appropriate instructions and guidelines for information on allowable personal exposure levels, proper respiratory protection and handling recommendations.



IMPORTANT

All personnel being responsible for the operation, installation, and maintenance of heat exchangers must carefully read and fully understand these instructions before transportation, loading/unloading, handling, installing, and servicing heat exchangers.



CAUTION

Microchannel evaporators and connecting pipework can operate at high pressure of refrigerants due to their nature of applications. It is essential to follow safety rules and recommendations when working with pressurized equipment, to use proper gauges and personal protection equipment. Only trained personnel can be allowed to install, commission, and maintenance of the evaporators.

CONTENT

Customer Services	1
Maintenance and Warranty	1
Service Contacts	1
Safety	2
Personal Protective Equipment and Handling	2
Refrigerant Warning	2
Introduction	4
Purpose of Present Manual	4
Product Applications	4
Product Advantages	4
Product Labeling	5
Operating Conditions	5
Refrigerants	5
Heat Exchanger Design	6
General Design	6
Materials	7
Microchannel Tubes	8
Airside Fins	9
Louvered Fins	9
Flat Fins	9
Manifolds	10
Refrigerant Distributor	10
Refrigerant Connections	11
Connection Location	11
Connection Type	11
Connection Orientation	12
Mountings and Fixtures	12
Protective Coatings	12
Epoxy Electrophoretic Coating	12
Trivalent Chromium Process Coating	14
Storage, Handling, and Transportation	15
Packing	15
Storage	15
Handling	16
Transportation	16
Installation	17
Coil Orientation	17
Inclination Angle	17
Locating Fans	17
Airflow Velocity	17
Condensate Behavior	17
Mounting	18
Airtightness	18
Thermal Expansion	18
Vibrations and Stresses	18
Connecting Refrigerant Lines	19
Refrigerant Charge and Evacuation	19
Refrigerant Charge	19
Refrigerant Evacuation	20
Maintenance	21
Maintenance Schedule	21
Cleaning Procedure	21
Repair	22
Services	23
Engineering	23
Selection Software	23

INTRODUCTION

Purpose of Present Manual

The purpose of the present manual is to guide engineers through the selection process of microchannel evaporator coils subject to application, operating and environmental requirements and conditions. The manual provides Kaltra customers with recommendations for evaporator installation, operating parameters, maintenance, and troubleshooting.



IMPORTANT

The development of Kaltra microchannel heat exchanger products are continuous, and the information in the present manual may not be up to date. Please check the current position with Kaltra.

Product Applications

Microchannel evaporators are intended for use as evaporator coils in wide range of air conditioning, cooling, and refrigeration applications and equipment. Evaporators are designed for use with a variety of refrigerants, including HFC- and HFO-based gases and derivative mixtures, natural refrigerants and blends. Microchannel evaporators are suitable for use in indoor and outdoor equipment, including cooling, dehumidification, and heat pump application.



IMPORTANT

Ensure your evaporator coil is suitable for use with your particular refrigerant prior to use! Allowable refrigerants are listed in supplied data sheets and on the product sticker.

Product Advantages

In comparison to other types of evaporators, microchannel coils offer significant advantages in performance and design:

- Significantly higher heat transfer performance thanks to brazed joints
- Low internal volume and up to 60% less refrigerant charge
- High corrosion resistance
- Closer approach temperatures
- Lower airside pressure drops
- Elimination of external refrigerant distribution devices/pipes
- Less weight
- Compact and robust design
- Easier maintenance and cleaning
- Optimized raw material cost
- Easy to recycle





Fig. 1: Microchannel coils vs. finned tube coils

Kaltra uses strong long-life aluminum alloys (SLLAs) in the manufacturing of microchannel tubes. These alloys - specially developed for HVAC applications - demonstrate ultimate corrosion resistance not found in other products. We offer surface treatments like electrocoating and trivalent chromium process (TCP) coating to boost corrosion protection even for the use of our heat exchangers in marine atmosphere and highly-polluted environments. Performance, quality, and other characteristics of our heat exchangers are confirmed by appropriate certifications, laboratory tests, and proven in the field.


Product Labeling

The product label identifies the product and provides essential information about the product and its use, including allowed refrigerant type(s), internal coil volume, design pressure and temperature. The product label is affixed to one of the heat exchanger manifolds.


MCHE		E	S	-	840	x	1080	-	25	/	13	-	26	H	42	-	L	23	-	R32
Application	E	Evaporator																		
Distributor	S	Inlet manifold only																		
	D	Inlet and outlet manifold																		
Width		mm																		
Height		mm																		
Tube width		mm																		
Tube thickness		mm • 10																		
Ports		Number of ports per tube																		
Manifold diameter		mm																		
Type of fins	L	Louvered																		
	F	Flat																		
Fin density		FPI																		
Refrigerant type(s)		ASHRAE number																		



Manufacturer S/N: MCHE-20020014588
 Manufacturing date: 02/2020
 Refrigerant type(s): R32
 Internal volume: 2.22 dm³
 Design pressure: 32 bar
 Design temperature: 120°C



MCHE-20020014588



Operating Conditions

Microchannel heat exchanger operating conditions		
Ambient air temperatures		
Minimum design temperature	°C	-40.0 ¹
Maximum design temperature	°C	120.0 ¹
Refrigerant temperatures		
Maximum design temperature	°C	120.0
Refrigerant pressures		
Design pressure	bar	20/32/45
Burst pressure	bar	100/140

¹ - for heat exchanger coils with e-coating: -40.0°C to 165.0°C; for heat exchanger coils with TCP-coating: -30.0°C to 150.0°C



IMPORTANT

Design operating pressure value can be found on the product label.

Refrigerants

Kaltra's microchannel evaporators are suitable for all HFC- and HFO-based refrigerants and mixtures composed of hydro-fluoro olefins and hydrofluorocarbons. Additionally, microchannel evaporators can be used with natural refrigerants - ammonia and range of hydrocarbon refrigerants, including propane and isobutane.

Refrigerants to use with microchannel evaporators shall comply with EN 378-2:2017 and/or AHRI Standard 700.



IMPORTANT

Refrigerants allowed to use with your microchannel evaporator are listed on the product label and/or datasheets supplied with the product.


HEAT EXCHANGER DESIGN

General Design

Microchannel heat exchangers are widely used in automotive applications due to their advantages of compactness, low weight, and high efficiency. For operation efficiency in stationary HVAC applications, microchannel evaporator design has been revised to offer uniformity in the refrigerant distribution along multiport tubes.

Uniformity of refrigerant flow distribution greatly affected by manifold construction and geometry. Significant improvement in refrigerant distribution is achieved by reducing the sectional area of the inlet manifold. Further improvement is achievable by the reduction of sectional areas of both inlet and outlet refrigerant manifolds.

Manifold construction includes refrigerant distributor – a tube inside a manifold featuring orifices to dispense refrigerant flow between the multiport tubes. Distributor dimensions and orifices diameter selected such that the ratio of the mass flow capacity of manifolds to the tubes flow capacity minimizes the maldistribution effect, uniformly feeds the refrigerant among tubes, thereby improving the overall performance of heat exchanger.



The layout of multiport tubes in microchannel evaporators is top-down, to ensure free drain-off behavior of condensate. Preferable flow direction is bottom-up. However, heat exchanger configuration with top-down flow direction is also possible. Inlet and outlet manifolds are located horizontally with microchannel multiport tubes extending therebetween. Evaporator coils can be configured for vertical, angled, and horizontal installations.

Evaporator coils allow a reverse operation to act as a condenser in heat pump applications.



IMPORTANT

When ordering an evaporator coil, it is necessary to specify whether it will operate in reverse (heat pump) mode, its desired installation angle, and select from bottom-up or top-down refrigerant flow direction.

Kaltra offers microchannel evaporator coils to order, with the length varying from 50mm to 2400mm and widths from 50mm to 2400mm, with different tube widths and manifolds diameters, refrigerant connections and mountings to customer specification. The following table summarizes possible evaporator configurations and properties:

General specifications			
Property	Units		
Max length	mm		2400
Max height	mm		2400
Tube width	mm		12.0 / 16.0 / 18.8 / 20.0 / 22.0 / 25.4 / 32.0 / 36.0
Tube spacing	mm		8.1 / 9.4 / 10.0
Manifold diameters	mm		16 / 20 / 25 / 30 / 32 / 38 / 42 / 50
Fin types			FLAT / LOUVERED
Fin pitch	FPI		10 / 16 / 18 / 19 / 21 / 23 / 24 / BY REQUEST
Design pressure	bar		20 / 32 / 45
Burst pressure	bar		100 / 140
Refrigerants			HFC / HFO / NATURAL
Protective coatings			NONE / E-COATING / TCP-COATING

Materials

Material properties are crucial for heat exchanger durability and corrosion resistance, especially when it comes to operating in aggressive atmospheres like highly-polluted industrial and urban areas, coastal zones, and other corrosive environments.


To achieve the highest product performances, Kaltra uses aluminum alloys and clads of series 3xxx, 4xxx, 7xxx, as well as strong long-life alloys (SLLAs) of series 9xxx.

Aluminum alloys						
Part	Alloy/Temper	Clad alloy/Temper	Coating	Additions/Modifications		
				Mn	Zn	Si
Multiport extrusion tubes (MPE)	AA3102-H112	-	Zn (ZAS)	0.4%	0.0÷0.3%	0.0÷0.4%
Multiport extrusion tubes (MPE)	AA3103-H12	-	Zn (ZAS)	0.9÷1.5%	0.0÷0.2%	0.0÷0.5%
Multiport extrusion tubes (MPE)	3F03-H112	-	Zn (ZAS)	0.9÷1.1%	0.2÷0.5%	0.6÷1.5%
Multiport extrusion tubes (MPE)	HA9153A-H112	-	Zn (ZAS)	0.7÷1.2%	0.2÷0.5%	0.6÷1.5%
Manifold tubes	AA4045	AA3003-H14/AA3005-H14	-	0.0%	0.0÷0.1%	9.0÷11.0%
Fin foil	FA7971	AA4343-H14SR	-	1.0÷1.5%	1.3÷1.7%	0.6%


The manufacturing of microchannel heat exchangers is an industrial CAB process - stands for controlled atmosphere brazing. CAB process is a flux-aided furnace brazing process under an inert shielding gas (nitrogen). Flux is required to clean the surfaces of the aluminum parts from oxides. For its microchannel heat exchangers, Kaltra uses the latest generation fluxes designed to give corrosion protection by controlled zinc load in addition to providing fin-to-tube joint filler formation. The silicon particles in the coating form the joint by reacting with aluminum, therefore replacing the use of clad fin. Aluminum alloys coated such a way exhibit excellent corrosion properties due to the formation of dense band of precipitates.

Coatings provide additional protection against corrosion and abrasion for microchannel tubes. Zinc arc spray process, implicating the projection of atomized molten zinc onto the surface to create a protective zinc diffusion layer, is a principal method to achieve high corrosion protection used in the manufacturing of microchannel tubes used in Kaltra's heat exchangers.

Putting a zinc layer on top of an aluminum alloy protects the core of the tube by providing a preferred path for corrosion to spread. Zinc is a less noble element compared to aluminum alloys. Zinc acts as a sacrificial layer guiding corrosion along the surface of the tube instead of through the tube walls. This corrosion behavior will lengthen the lifetime of the tube. With zinc arc spraying, an even coating with a good metallic bond is formed on the tubes, and this zinc layer will diffuse into the microchannel tube core during brazing.



The dense band of precipitates (brown), formed during brazing of long-life alloys, is the key to producing the excellent corrosion performance compared with conventional alloys.



The composition of silicon and magnesium makes tube alloys easy to braze in the controlled atmosphere brazing process while showing good corrosion resistance after brazing.



Optimized aluminum alloy composition contributes to a high strength after brazing and provides sacrificial layer to improve the long-term corrosion resistance for microchannel tubes.

Microchannel Tubes

Heat exchangers can be configured and manufactured with flat microchannel tubes - also referred to as multiport extrusion (MPE) tubes - of different widths, geometry, port quantity, and port sizes, depending on customer requirements, refrigerant type, and performance demands. Standard or long-life aluminum alloys are the materials for microchannel tubes used in the manufacturing of Kaltra heat exchangers. High manganese-containing, zinc-coated long-life alloys exhibit excellent corrosion properties thanks to the formation of dense band of precipitates (DBP).




Fig. 3A: Medium-pressure MPE tube




Fig. 3B: High-pressure MPE tube

Microchannel tubes are fabricated using direct hot extrusion through hollow dies and characterized by specifically selected alloys and coatings, tolerances, which have been optimized for special cooling and refrigeration applications. As standard, the following tubes with the widths from 12mm to 36mm are available for evaporator coils:

Microchannel tube specifications - evaporator coils						
Sectional view	Code	Tube width	Tube thickness	Ports	Wall thickness	Applications
		mm	mm		mm	
	H12/12-12	12.0	1.2	12	0.30	HIGH PRESSURE / MEDIUM PRESSURE
	H16/13-16	16.0	1.3	16	0.28	HIGH PRESSURE / MEDIUM PRESSURE
	S16/17-15	16.0	1.7	15	0.30	GENERAL PURPOSE / UNIVERSAL
	S18/19-13	18.8	1.9	13	0.28	LOW PRESSURE / MEDIUM PRESSURE
	H20/13-22	20.0	1.3	22	0.28	HIGH PRESSURE / MEDIUM PRESSURE
	S20/20-10	20.0	2.0	10	0.35	LOW PRESSURE / MEDIUM PRESSURE
	H20/20-12	20.0	2.0	12	0.27	LOW PRESSURE / MEDIUM PRESSURE
	S20/20-12	20.0	2.0	12	0.40	GENERAL PURPOSE / UNIVERSAL
	S22/20-12	22.0	2.0	10	0.35	GENERAL PURPOSE / UNIVERSAL
	H25/20-20	25.4	2.0	20	0.32	HIGH PRESSURE / MEDIUM PRESSURE
	H25/13-26	25.4	1.3	26	0.28	HIGH PRESSURE
	S25/20-15	25.4	2.0	15	0.27	GENERAL PURPOSE / UNIVERSAL
	H25/20-13	25.4	2.0	13	0.33	HIGH PRESSURE / MEDIUM PRESSURE
	H32/13-32	32.0	1.3	32	0.30	HIGH PRESSURE / MEDIUM PRESSURE
	S32/20-16	32.0	2.0	16	0.35	GENERAL PURPOSE / UNIVERSAL
	H32/20-25	32.0	2.0	25	0.32	HIGH PRESSURE / MEDIUM PRESSURE
	H36/13-36	36.0	1.3	36	0.30	HIGH PRESSURE / MEDIUM PRESSURE
	H36/20-26	36.0	2.0	26	0.33	HIGH PRESSURE / MEDIUM PRESSURE
	H36/20-29	36.0	2.0	29	0.50	HIGH PRESSURE
	S36/20-16	36.0	2.0	16	0.36	GENERAL PURPOSE / UNIVERSAL



IMPORTANT

Microchannel tubes with higher wall thickness withstand corrosion better and recommended for installations in high-corrosive environments.



IMPORTANT

It is necessary to select microchannel tubes qualified for refrigerant used in the system. For allowable design operating and burst pressures, refer to the product label or documentation supplied with the heat exchanger.

Airside Fins

Kaltra microchannel heat exchangers can be designed with either louvered or flat fins, depending on desired performance, application conditions and customer requirements. Louvered fins offer significantly higher heat transfer characteristics but also higher pressure drop on the airside, while heat exchangers with flat fins demonstrate better characteristics in some specific applications like operation in frosting conditions.

Louvered Fins

The louvered fins enhance the heat transfer by providing multiple flat-plate leading edges with their associated high values of heat transfer coefficient. Louvered fins enhance heat transfer by a factor of 2 to 3 compared with equivalent flat surfaces. The louvers have the further advantage that the enhancement of heat transfer is gained without a significant increase in flow resistance.

In louvered fins, fin height, louver angle, number of louvers, louver pitch and fin geometry as a whole are selected for an optimum balance of heat transfer and air resistance.

Flat Fins

Flat fins also advantageous for industrial applications as flat fin coils tend much less to airside fouling. Industrial coils generally operate with higher air-to-refrigerant temperature delta, and, if that is the case, the surface area of flat fins perfectly matches the application.

The fins of flat design are generally intended for evaporator applications with low moisture loadings as they do not provide enough condensate drainage.




Fig. 4A: Louvered fins







Fig. 4B: Flat fins

Heat exchangers can be manufactured with different fin pitches, from 10FPI to 24FPI, to suit desired performance, air resistance, and other requirements. Custom fin types and pitches are available on request. As standard, fin thickness is 0.08mm; fin height is 8.0 or 8.1mm; fin strip width matches microchannel tube width.

Fin specifications - evaporator coils					
Sectional view	Code	Fin height	Fin width	Gauge	Fin density
Louvered fins		mm	mm	mm	FPI
	L81/120	8.10	12.0	0.08	21.0 / 23.0
	L81/160	8.10	16.0	0.08	18.0 / 19.5 / 21.0 / 23.0
	L80/188	8.00	18.8	0.08	21.0 / 23.0
	L81/200	8.10	20.0	0.08	21.0 / 23.0
	L80/200	8.00	20.0	0.08	10.0 / 16.0 / 19.5 / 21.0 / 23.0 / 24.0
	L80/220	8.00	22.0	0.08	21.0 / 23.0
	L81/254	8.10	25.4	0.08	21.0 / 23.0
	L80/254	8.00	25.4	0.08	18.0 / 19.5 / 21.0 / 23.0
	L81/320	8.10	32.0	0.08	21.0 / 23.0
	L80/320	8.00	32.0	0.08	10.0 / 16.0 / 18.0 / 19.5 / 21.0 / 23.0 / 24.0
Flat fins		mm	mm	mm	FPI
	F80/200	8.00	20.0	0.10	10.0
	F80/320	8.00	32.0	0.10	10.0

Manifolds

Manifolds of microchannel evaporators are round tubes, manufactured from AA4045 aluminum alloy with AA3003-H14 or AA3005-H14 clad alloys, providing excellent performance in the brazing and improved corrosion resistance in applications. The selection of manifolds with diameters from 16 to 50mm and wall thickness from 1.2mm to 2.5mm ensures optimum choice for any refrigeration system design and refrigerants.

Manifold specifications - evaporator coils				
Sectional view	Code	Tube diameter	Wall thickness	Applications
		mm	mm	
	16/120	16.0	1.20	UNIVERSAL
	20/150	20.0	1.50	UNIVERSAL
	25/150	25.0	1.50	UNIVERSAL
	28/140	28.0	1.40	UNIVERSAL
	30/150	30.0	1.50	UNIVERSAL
	32/175	32.0	1.75	LOW PRESSURE / MEDIUM PRESSURE
	32/250	32.0	2.50	HIGH PRESSURE
	38/200	38.0	2.00	UNIVERSAL
	38/250	38.0	2.50	HIGH PRESSURE
	42/200	42.0	2.00	UNIVERSAL
	42/250	42.0	2.50	UNIVERSAL / HIGH PRESSURE
	50/200	50.0	2.00	UNIVERSAL
	50/250	50.0	2.50	UNIVERSAL / HIGH PRESSURE




IMPORTANT

Selecting correct manifold size is essential for proper refrigerant distribution along microchannel tubes and optimal evaporator operation under partial and full heat loads. Consult with Kaltra engineers for details.

Refrigerant Distributor

The distributor provides uniform dispensing of two-phase, gaseous and liquid, refrigerant along multiport tubes, thereby improving coil performance and efficiency under partial and full load conditions. Depending on the selected design, distributors can be installed either inside the inlet manifold only or inside both inlet and outlet manifolds of the evaporator coils. Both designs are suitable for reverse-cycle (heat pump) operation. Refrigerant distributors are provided with orifices to dispense refrigerant flow between tubes.



Refrigerant distributor for evaporator coil selected based on the maximum design load and operating mode - evaporation-only or evaporation/condensation. Refrigerant pressure drop induced by the distributor has no effect on overall evaporator operating pressure and evaporation temperature.



IMPORTANT




To ensure a stable evaporator operation, the expansion valve shall be selected with the exclusion of the value of pressure drop induced by the refrigerant distributor.

Refrigerant Connections

Refrigerant connections of evaporator coils are primarily copper type. However, other types (stainless steel, carbon steel, aluminum) are also available for the ordering. Diameter, length, bend angle, location - all are to the customer specification. As copper and aluminum are dissimilar metals, adhesive shrink sleeves are used to avoid corrosion at copper-to-aluminum joints.

Connection Location

Depending on the design conditions, evaporator connections can be located on the manifold's end or its side, or the coil face. Refrigerant connections can be chosen individually for refrigerant inlet and outlet.






Connection Type

Customers may choose suitable types of refrigerant connections. As standard, available connection types include:

- Sweat copper pipe connections
- Copper pipe with soldered in threaded brass fittings
- Aluminum flanged connections
- Stainless steel threaded connection pipes
- Carbon steel threaded connection pipes

Connections of different types, standards, and specifications are available as per customer request.



Microchannel coils may be supplied with the following sealing fittings:

- Shrader valves: required for coils charged with over 1 bar gas (nitrogen) pressure
- Brazed-in end caps: required for coils charged with over 1 bar gas (nitrogen) pressure
- Rubber plugs: for coils charged with the pressure lower than 1 bar
- Plastic caps: for empty coils
- No fittings: for empty coils

**IMPORTANT**

Consult with Kaltra engineers to select a connection type suitable for refrigerant to be used.

Connection Orientation

Depending on incoming refrigeration pipework and other application requirements, evaporator coil connection pipes could be manufactured in the following geometries:

- Straight
- Elbowed at any angle in coil plane
- Elbowed in two or more planes

Connections could be of a single-pipe design or could be branched to dispense a refrigerant to and from coil manifolds.

Mountings and Fixtures

Kaltra offers more than a dozen of mounting brackets of various geometries attached to coil manifolds. These mountings are designed considering thermal expansion of the coil, to give flexibility in installation, and to firmly support coil weight. Additionally, coils can be manufactured with fixtures on side reinforcement bars. Customized mounting fixtures and accessories are available on request.

Protective Coatings

Corrosion, the deterioration of metals and alloys through a physical and/or chemical reaction with the environment, may affect the heat exchangers, specifically condenser and cooling/heating coils that are exposed in the environment, and this can lead to failures and performance degradation of the equipment in the cases of improper heat exchanger protection in corrosive locations. Potentially corrosive environments include coastal and marine areas, locations adjacent to industrial and urban areas, locations with proximity to heavy road traffic, factories, power plants, chemical plants, or the combinations of the above.

Unprotected heat exchangers, regardless of their type, are subjected to corrosion. Although all-aluminum microchannel coils tend to be less affected by corrosion compared to multi-metal coils, the protection must be applied in order to prevent deterioration in aggressive atmospheres. The highest level of corrosion resistance can be achieved with the properly applied coil coating. For microchannel heat exchangers, the best coating option is factory-applied electrodeposition, which is also referred to as electrocoating (e-coating) or electrophoretic deposition, and produce uniform finishing with excellent corrosion resistance. The trivalent chromium process (TCP) coating is another efficient method of protection with excellent anti-corrosion properties. Kaltra offers both E-coating and TCP-coating as an option for all heat exchangers. Other coating types are available on request.

For more information on protective coatings and anti-corrosion solutions for microchannel heat exchangers, refer to appropriate Kaltra selection guidelines and manuals available online.

**IMPORTANT**

Consult with Kaltra engineers regarding the best suitable protective solution for your heat exchanger application.

**CAUTION**

Coated coils are not intended for liquid immersion applications.

**IMPORTANT**

The effect of protective coatings on heat transfer rate is typically 1%, and up to 5% on airside pressure drop. These values shall be taken into account when selecting a heat exchanger.

Epoxy Electrophoretic Coating

Epoxy electrophoretic coating (e-coating) is a process based on the deposition of electrically charged particles out of a water suspension to coat a heat exchanger. During the process, paint is applied to a heat exchanger with particular film thickness regulated by the amount of applied voltage and builds up an electrically insulating layer. The deposition process is self-limiting and stops as the applied coating electrically insulates the surface of a heat exchanger – thus guaranteeing substantial film thickness and complete surface coverage for such complex-shaped parts as microchannel heat exchangers.

Electrocoat process includes four distinct phases:

- Pre-treatment: cleaning the heat exchanger surface and phosphating. This stage includes immersion degreasing, rinsing, and phosphating, which is essential to achieving performance requirements and guarantees that no contaminations in the form of acids or electrolytes enter the electrocoat bath
- Applying the coating in an electrocoat bath. The bath is filling with paint emulsion (10-20%), solvents, and deionized water (80% and more), which is used as a carrier for the paint solids. The electrocoat process is driven by a DC rectifier, used to control the amount of paint that is deposited onto the heat exchanger surface. Cathodic deposition method with positively charged paint particles which are attracted to negatively charged heat exchanger characterizes by better corrosion resistance and high UV resistance of the end-product – compared to the anodic process. Thank electrical attraction, paint particles also penetrate the flaws and cracks in the metal
- Post-coating rinsing. Excessive paint is removed from the heat exchanger surface during this stage, providing a higher level of efficiency and aesthetics
- Thermal curing using bake oven. This process cures and cross-links the paint film to ensure maximum performance and corrosion resistance for the heat exchanger



Fig. 8A: Uncoated microchannel heat exchanger



Fig. 8B: E-coated microchannel heat exchanger

Electrocoatings are typically made from polymeric resins, solvents and diluents, and pigments. Resin is a base of the paint which provides protection against corrosion and ultraviolet durability. Pigments and solvents provide coloring, glossing, and smooth appearance of the end product. The nature of the resins for the electrocoating can vary, but any type of resin feature functional groups in the backbone which allows them to become ionic in the presence of neutralizing agents. Electrocoating offers significant advantages over other coating technologies:

- High corrosion protection. Cathodic epoxy electrocoating with a film thickness of 20 microns withstands more than 6000 hours salt spray test performed in accordance with ASTM B117 standard, more than 4000 hours SWAAT performed in accordance with ASTM G85 Annex A3
- Uniform coating with no more than 1-2 micron variances across the coated surface of any shape complexity
- Eco-friendliness: heavy metal free, no hazardous air pollutants (HAPS), low levels of organic solvents, and low volatile organic compounds (VOC)
- Aesthetic quality

Performance test results: e-coated microchannel heat exchanger

Test	Standard	Results
Dry film thickness	ASTM D7091	15-50µm
Film hardness	ASTM D3363	>2H
Adhesion rating	ASTM D3359	0.0<ΔE<1.0
Salt spray test	ASTM B117	6000hrs
Water resistance in 100%rH	ASTM D2247	>1000hrs
Hot water dip test	ASTM D870	>1000hrs
Specular gloss test	ASTM D523	60-90
Copper-accelerated acetic acid-salt spray test, CASS	ASTM B368	>1000hrs
Sea water acetic acid test, SWAAT	ASTM G85 Annex A3	>4000hrs
UV resistance test	ASTM G154	>2000hrs

E-coating is resistant to the following chemicals at ambient temperatures. Elevated temperatures can have an adverse effect on the corrosion durability of the coating product, depending on the specific environment. Data for the corrosion resistance of e-coating in specific corrosive environments available upon request.

E-coating chemical resistance				
Acetates (all)	Acetic acid	Acetone	Acetylene	Acrylonitrile <10%
Alcohols (all)	Aldehydes (all)	Alum	Amines (all)	Amino acids
Ammonia	Ammonium hydroxide	Ammonium nitrate	Amiline	Benzene
Benzoic acid	Benzol	Borax	Boric acid	Butyl alcohol
Butyl cellosolve	Butyric acid	Calcium chloride	Calcium hypochlorite	Carbolic acid
Carbon dioxide	Carbon monoxide	Carbon tetrachloride	Carbonates (all)	Carbonic acid
Cetyl alcohol	Chlorides (all)	Chlorinated solvents (all)	Chlorine gas	Chloroform
Chromic acid	Citric acid	Creosol	Diesel fuel	Diethanolamine
Esters (all)	Ethers (all)	Ethyl acetate	Ethyl alcohol	Ethyl ether
Ethylene oxide	Fatty acid	Fluorine gas	Formic acid <10%	Formaldehyde <27%
Formic acid <10%	Freon	Fructose	Fuels (all)	Gasoline
Glucose	Glycols (all)	Hydrazine	Hydrocarbons (all)	Hydrochloric acid <10%
Hydrofluoric acid	Hydrogen	Hydrogen peroxide 5%	Hydrogen sulfide	Hydroxylamine
Iodides (all)	Iodine	Isobutyl alcohol	Isopropyl alcohol	Kerosene
Ketones (all)	Lacquers	Lactic acid	Lactose	Lauryl acid
Magnesium	Maleic acid	Menthol	Methanol	Methyl ethyl ketone
Methyl isobutyl ketone	Methylene chloride	Mustard gas	Naphthol	Nitric acid
Nitrides (all)	Nitrobenzene	Nitrogen fertilizers	Oils (mineral, vegetable)	Oleic acid
Oxalic acid	Ozone	Perchloric acid	Phenol 85%	Phenolphthalein
Phosgene	Phosphoric acid	Potassium chloride	Potassium hydroxide	Propane
Propyl alcohol	Propylene glycol	Salicylic acid	Salt water	Sodium bisulfite
Sodium chloride	Sodium hydroxide <10%	Sodium hypochlorite 5%	Sodium sulfate	Starch
Stearic acid	Sucrose	Sulfate liquors	Sulfates (all)	Sulfides (all)
Sulfites (all)	Sulfonic acid	Sulfur dioxide	Sulfuric acid 25-28%	Surfactants
Tannic acids	Tetraethyl lead	Toluene	Triethanolamine	Vinegar
Xylene				

Trivalent Chromium Process Coating

Trivalent chromium process (TCP) is a type of conversion coating used to passivate aluminum alloys as a corrosion inhibitor. Unlike hexavalent chromium, trivalent chromium is non-toxic (both TCP bath and the resulting film contain no hexavalent chromium species) and fully complies with RoHS (Restriction of Hazardous Substances) requirements.

During TCP coating formation, activation of the aluminum surface leads to the reactions of oxygen reduction and hydrogen evolution, which results in the pH increase and the deposition of the TCP coating. TCP coating is characterized as a dense layer consisting of rounded particles hundreds of nanometre in size. The TCP coating consists of a two-layer structure, with zirconium-chromium oxide in the outer layer and aluminum oxide or oxyfluoride at the aluminum/coating interface. The TCP coating provides corrosion protection to aluminum alloys through suppressing the oxygen reduction reaction on aluminum alloy surfaces by acting as a protective barrier layer.

Trivalent chromium pretreatment demonstrates outstanding results for corrosion resistance and provides more than 3150 hours in neutral salt spray (ASTM B117), more than 2500 hours in sea water acetic acid test (SWAAT), and even longer for SLLA aluminum alloys used in Kaltra heat exchangers. TCP coating also exceeds dry tape adhesion requirements for ASTM D3359.

Performance test results: TCP-coated microchannel heat exchanger		
Test	Standard	Results
Adhesion rating	ASTM D3359	0.0< ΔE <1.0
Salt spray test	ASTM B117	3150hrs
Sea water acetic acid test, SWAAT	ASTM G85 Annex A3	>2500hrs

Applying of trivalent chromium process coating consists of the following steps (post-treatment is required depending on aluminum alloy grade being processed):

- Removing pollutants from the heat exchanger surface by rinsing and degreasing in an alkaline bath
- Immersion in a desmutting bath in order to remove coarse intermetallic particles and native oxide
- Forming of TCP coating by immersion of the heat exchanger in a trivalent conversion bath
- Post-treatment to reinforce the conversion layer and drying with the dried air stream
- The heat exchanger is rinsed in deionized water following each step

STORAGE, HANDLING, AND TRANSPORTATION

Packing

Microchannel heat exchangers are supplied tightly packed in vertical position in wooden crates to avoid sliding, moving, and deformation of the coils during transportation. Crates are reinforced with wooden beams on the bottom side, and on the top are closed with screws. Internal packing includes partitioning cardboards and plastic sealings to prevent heat exchangers from coming into contact with each other and with the crate walls.

Supplied heat exchangers are sealed and charged with nitrogen gas at 0.05÷0.20MPa pressure (except those shipped by air).



IMPORTANT

Handling instructions and crate content can be identified by reading stickers applied to the crate walls.

Storage

Microchannel heat exchangers shall be stored indoors in a dry and clean environment under the following conditions:

- The storage temperature range is -40°C to 120°C (-40°F to 250°F)
- Avoid exposure to direct sunlight
- During storage, exposure to corrosive environments shall be effectively avoided
- Metal chips and/or copper or steel dust can cause galvanic corrosion: storage and installation areas must remain clean and separate from machining or welding areas
- Heat exchangers shall be stored in a vertical position, preferably in the original package until they are installed in the equipment
- Do not stack heat exchangers flat on top of each other
- Improper storage and stacking of microchannel heat exchanger can cause premature corrosion or deformation and may reduce its service life
- With prolonged storage, suitable measures for additional corrosion protection should be implemented following consultation with Kaltra



IMPORTANT

Heat exchangers must be stored free of fluids and with protective caps on refrigerant connection pipes to avoid corrosion and/or contamination.



IMPORTANT

Avoid storing heat exchangers in horizontal position for a long period of time.




Fig. 9. Position for long-term storage

Handling

Although microchannel coils are robust construction, care must be taken to ensure that damages and leaks are not caused by improper handling. Airside fins of microchannel coil are harder to be bent compared to those used in finned tube coil designs. The lightweight construction of microchannel allows handling the coil by hand.

Use lifting lugs or mountings located on microchannel coils for assisted installation and removal and avoid the use of straps being wrapped around the coil surface.

Clean the heat exchanger prior to installation, if necessary. Do not use chemicals for cleaning. Rinse only! For details of the cleaning procedure, refer to the appropriate section of the present manual.



IMPORTANT

To avoid damages, never lift the microchannel coil by the refrigerant connection pipes.



CAUTION

Avoid dropping, impacting, placing heavy objects on top of, stepping on microchannel coil as this may cause coil warps.



CAUTION

Always consider maximum weight of parts to handle. Use appropriate lifting and supporting devices to move heavy items.



CAUTION

Check the heat exchanger is as ordered, discrepancies or transit damage should be reported to Kaltra immediately. Care should be taken to ensure the unit does not sustain damage before it is installed. It is strictly prohibited to use the connections, which are delicate parts of the coil, as anchoring points when lifting or handling the unit. This would cause serious damage to the coil and serious risks for the safety of persons and goods.

Transportation

Heat exchangers can be transported individually or stacked on wooden pallets. It is recommended to transport heat exchangers for long-distance hauls in the original package.

Avoid continuous vibration during transportation, as this may cause heat exchanger damage.



CAUTION

During transportation and handling, avoid exerting undue pressures, accidental hits, and avoid any shocks that could damage the product.



CAUTION

Kaltra accepts no responsibility for any mishandlings during unit lifting or moving.

INSTALLATION

The installation should be carried out by trained and experienced specialists in accordance with common refrigeration practice, recommendations of the present manual, local rules and requirements and directives in force.



IMPORTANT

Kaltra takes no responsibility for improper installation, which may cause heat exchanger malfunction or damage to the equipment.

System designer and installing engineer should be responsible for checking and observing all the requirements in accordance with system application and installation.



IMPORTANT

Prior to installation, clean heat exchanger, if necessary. Refer to the appropriate section in the present manual for cleaning instructions. Evacuate nitrogen gas from the coil. It is recommended to insert connection plugs back and not to remove plugs until required.

Coil Orientation

Before installation, identify the location of inlet and outlet refrigerant connections. For proper operation of the refrigerant distributor, a liquid refrigerant line shall be connected to an inlet coil manifold equipped with the distributor.

Refer to the product label, identification marks on connection pipes, or documentation supplied with a heat exchanger to identify inlet and outlet connections.

Inclination Angle

The installation angle plays a role in evaporator performance, as, in turn, the inclination angle affects air velocity to the coil face and moisture load. Inclination angle also affects tubeside refrigerant flow due to the influence of gravity forces.

Evaporators demonstrate good performance with installation angles from vertical to horizontal, with the optimum efficiency in the range from 75 to 45 degrees.

Locating Fans

Uniform airflow distribution over the coil face is essential to achieve maximum evaporator performance. Select and position the fans for optimum air stream distribution. Determine the required distance from fan impeller to the coil face.

Airflow Velocity

To assure no water droplets/mist entertainment in the air stream, the maximum airflow velocity for evaporator coils shall not exceed 2.5m/s. For outdoor equipment or in cases when moisture carry-over is not an issue, air velocity can be lifted to achieve higher evaporator performance.

Condensate Behavior

In evaporator operation, condensate may accumulate on the fins. As water droplets become large by coalescence and grow large enough to fall, condensate water pulls down through the fin louvers by gravity and capillary forces. The higher the latent moisture load, the higher the evaporator performance. In microchannel evaporators, free condensate drainage is provided by the vertical arrangement of multiport tubes. Louvered fins ensure free condensate drainage, as opposed to the fins of flat design.

Condensate behavior is also affected by the inclination angle of the heat exchanger:

- For inclination angles close to vertical: condensate water flows downward via gravity pull, with no blow-off effect for air velocities of up to 2.5m/s
- Inclination angles close to 75 to horizontal: condensate water flows downward via gravity pull, with more condensate on the trailing side of the fins. At high latent loads, the condensate also follows the tube line down. No condensate blow-off expected for air velocities of up to 2.5m/s
- Inclination angles close to 45 to horizontal: condensate water flows downward via gravity pull, with most condensate flowing along the tube line and dripping off the face of the coil, in the bottom half of the coil
- Inclination angles from 45 to flat: more condensate is held up in the fins, latent performance declines, and condensate is pushed forward to drip off the face of the coil

**IMPORTANT**

Evaporator coil shall be mounted above condensate drain pan. Avoid contacts between the coil and condensate pan in order to prevent corrosion issues, bacterial growth, and thus to assure long operating life for the evaporator.

Mounting

Heat exchanger mounting shall be conducted with attention to the airtightness of assembly, thermal expansion/contraction of the coil due to ambient and/or refrigerant temperature change, vibrations induced by unit components like fans and compressors. Special attention shall be paid to eliminate direct contact between aluminum coil core and other equipment parts/components made of dissimilar metals as this may cause galvanic corrosion.

Airtightness

In order to maximize heat exchanger performance, it shall be sealed with rubber or plastic band all round. This way, airtight minimizes airflow waste, even in the case of thermal coil contraction. Inter alia, rubber/plastic band isolates evaporator coil from the framing, thus eliminating a possible source of corrosion, while minimizes vibration issues.

Thermal Expansion**IMPORTANT**

The thermal expansion of aluminum is higher than most other metals, and this shall be taken into account during the system design phase and its installation.

The table herein shows the minimum recommended allowance for thermal expansion based on the heat exchanger dimensions, assuming an 80°C temperature differential. If high ambient or low ambient operation is expected, thermal expansion allowance shall be increased based on the maximum discharge temperature at the high-pressure safety cutout, minus the lowest expected ambient operating temperature.

Thermal expansion allowances	
Heat exchanger length/width	Thermal expansion allowance ¹
mm	mm
≤200 TM D1001	0.25
≤350	0.40
≤500 TM D3005	0.60
≤650	0.75
≤800 TM D3007	0.90
≤1000	1.10
≤1250 TM D5013	1.30
≤1500	1.50
≤1750 TM C80 A1000 A3	1.75
≤2000	2.00
≤2250 TM D5015	2.25
≤2500	2.50
≤2750 TM C80 A1000 A3	2.75
≤3000	3.00

¹ - for 80°C temperature differential

To avoid the risk of coil damage caused by thermal expansion, microchannel heat exchangers shall be mounted with fixtures allowing the coil to expand freely in both horizontal and vertical directions. The same shall be taken into account when locating the refrigerant pipe supports. Inlet/outlet refrigerant connections shall be supported so that the brazed joints are not exposed to stress or tension.

Vibration and Stresses

Vibrations that exceed allowable range may cause leaks and other damages to microchannel heat exchangers. The recommended method of eliminating vibrations is using rubber/plastic washers or inserts on coil mountings and/or install heat exchanger manifolds with rubber/plastic supports. Rubber or plastic band that used for airtightness of the coil assembly also absorbs vibrations.

The below table indicates the allowable vibration range. Make sure the levels of vibrations do not exceed specified limits.

Vibration allowances			
Property		Allowance	
Amplitude	mm	≤0.15	
Peak amplitude	mm	0.25	
Acceleration	m·s ⁻²	≤20	

**CAUTION**

Warranty does not cover the cases related to heat exchanger damage caused by exceeding vibrations.

Connecting Refrigerant Lines

In order to join the coil with copper refrigerant pipework of the unit, the coils may have a manufactured brazed copper-to-aluminum connection covered with adhesive shrink sleeve to avoid corrosion between these dissimilar metals. The protection of this joint is required when brazing the copper-to-copper connections. This can be accomplished by placing a wet rag or heat paste over the shrink sleeve during the brazing process.

**CAUTION**

When brazing in the new microchannel coil, the temperature at the copper-to-aluminum joint must not exceed 250°C. Failure to follow this requirement could result in coil damage.

**IMPORTANT**

Place an aluminum splatter shield using aluminum foil tape during the brazing to protect the heat exchanger from galvanic corrosion associated with splatter during the brazing process.

Refrigerant Charge and Evacuation

**CAUTION**

Over-pressurization of the refrigeration system can cause explosive discharge of high-pressure refrigerant, loss of refrigerant, environmental pollution, equipment damage, injury, or death. Use extreme caution when charging the refrigerant system. Do not pressurize the system higher than the design pressure marked on the unit's nameplate.

It is essential that the system is charged with the correct amount of refrigerant. Remember, an overcharged or undercharged system may lead to major component failure. The final refrigerant charge level should be set by the design evaporating and condensing pressures. The suction and discharge pressures should be continuously monitored while charging is in progress.

Refrigerant Charge

**CAUTION**

Heat exchangers are shipped with a holding charge of inert gas to guard against contamination or moisture during transportation and storage. The charge should be checked to indicate if leaks are present before evacuation. If the charge appears to be either partially or totally lost, then the heat exchanger shall be checked for signs of physical damage.

**CAUTION**

Pressure testing can be dangerous if not properly conducted. Personnel undertaking pressure testing must be technically competent and suitably qualified.

The microchannel heat exchanger features up to 60% smaller internal volume that results in a refrigeration system that requires less refrigerant than a comparable unit with a finned tube coil. Due to this, the charging of these units is critical. It is very easy to overcharge a unit with a microchannel coil. Kaltra recommends to follow the below rules when charging microchannel coil:

- Use a digital scale to weigh in, or out, the refrigerant when you are adjusting the charge
- Charge the system with the calculated amount of refrigerant
- Add or remove only a small amount of refrigerant per adjustment and wait at least 15 minutes per adjustment. Allow the pressure in the system to stabilize before adding more refrigerant
- Repeat the last step until the system is fully charged

Refrigerant Evacuation

Refrigerant evacuation shall be carried out as follows:

- Use a high vacuum pump and connect to the high- and low-pressure sides of the system via a gauge manifold fitted with compound gauges, a high vacuum gauge shall be fitted to the system at the furthest point from the vacuum pump
- The system shall be evacuated to 0.5 Torr and if achieved no further evacuation steps are required
- Triple evacuation shall be used to ensure that all contaminants are removed if initially 0.5 Torr could not be achieved
- Operate the vacuum pump until a pressure of 1.5 Torr absolute pressure is reached, then stop the vacuum pump to break the vacuum using oxygen-free nitrogen until the pressure rises above zero
- The above operation shall be repeated a second time
- The system shall then be evacuated a third time, but this time to 0.5 Torr absolute pressure

MAINTENANCE

Timely servicing is essential to maintain optimum performance of the microchannel heat exchanger and ensure its long operating life. Observe Kaltra's recommendation on the after-sale service described below.



CAUTION

All work must be carried out by technically trained competent personnel. Prior to servicing heat exchangers, be sure to disconnect the power supply and lock power switch to prevent the power from accidentally being turned on.



CAUTION

It is owner responsibility to provide scheduled maintenance in accordance with the schedule and requirements mentioned below. Incorrect maintenance within warranty period invalidates warranty obligations of the manufacturer. It is important to follow maintenance schedule as a minimum not only for warranty period but for the whole life time of the heat exchanger.

- All service records shall be accurately documented
- Appropriate service tools, test and safety equipment should be employed for maintenance works

Maintenance Schedule

The maintenance schedule indicates the time between maintenance operations. It is necessary to carry out all maintenance tasks described below in case the system has been stopped for a period longer than three months.

Maintenance schedule	
Item	Work description
Interval: 6 months	
Cleaning ¹	Check if heat exchanger cleaning is required and perform cleaning procedure as described in the present manual.
Check for vibrations	Check if vibrations do not exceed allowable limits and eliminate vibration source, if necessary.
Check heat exchanger condition	Check the heat exchanger visually for mechanical damages; check the condition of rubber/plastic elements and replace, if necessary.
Leakage check ¹	Check the heat exchanger visually for leakages or traces of refrigerant spill outs. Pay special attention to refrigerant connections. Perform repair, if necessary.
Interval: 12 months	
Assembly check	Check all bolted connections for tightness. Tighten connections, if necessary.
Check for corrosion ¹	Check the heat exchanger for traces of corrosion.
Coating check ¹	For heat exchangers with protective coatings, check the coating for scratches. Repair, if necessary.

¹ - Inspection and maintenance intervals should be shortened according to the actual situation if the heat exchanger operated in aggressive, corrosive, or highly-polluted environments.

It is essential to change air filters installed within airstream before the evaporator timely to protect the coil from the dust and avoid the restriction of designed airflow.

Cleaning Procedure

The build-up of dirt on the aluminum surface, which is exposed to moisture, can reduce the durability of the heat exchanger. Regular cleaning of the heat exchanger ensures its high efficiency in operation.



CAUTION

Warranty claims related to cleaning damage or corrosion resulting from chemical coil cleaners, will not be honored.

In comparison to finned tube heat exchangers, microchannel coils tend to accumulate dirt and debris on the surface rather than inside, making them easy to clean. The cleaning procedure for microchannel heat exchangers includes the following steps:

- Remove dirt and debris from the coil surface with a soft brush or vacuum cleaner with a soft attachment or compressed air blower (3 to 5 bar)
- Microchannel coils could retain water after cleaning. Blow off or vacuum out the residual water from the coil to speed up drying

- Rinse the coil with water (pH in range 4.5÷8.5), including general detergents. Do not use chemicals to avoid corrosion potential. Use the water-atomizing nozzle to prevent possible damages from the water stream. Water pressure must be controlled to prevent damage to the fins: sprayer nozzle pressure should not exceed 40 bar

**CAUTION**

During cleaning, wear proper personal protective equipment such as a face shield, gloves, and waterproof clothing.

**CAUTION**

Brush the coil in the longitudinal direction of fins only.

**CAUTION**

Align the cleaning nozzle at the angle to coil fins. Nozzle angle should not exceed 25 degrees to the coil surface.

**CAUTION**

During high-pressure cleaning, keep the minimum distance of 400mm from the spraying nozzle to the coil surface.

**IMPORTANT**

Clean the coil from the opposite direction of normal air flow as this allows the debris to be pushed out rather than forced further into the coil.

Repair

If the leak is found to be within the microchannel tubes of the coil, a field repair kit is available from Kaltra. A heat gun and needle-nose pliers are required tools for the repair procedure.

**CAUTION**

Sharp edges! The service procedure described in the present manual involves working around sharp edges. To avoid being cut, technicians must put on all necessary personal protective equipment, including gloves and arm guards. Failure to follow recommendations could result in injury.

- Locate the source of the leak
- Evacuate any remaining refrigerant in the damaged coil circuit
- Using needle-nose pliers, clear away approximately 1 cm of fin material from each side of the leak to gain access to the repair area
- Prepare the aluminum wrapper by cutting it to approximately 5cm in length and folding it in half
- Using the aluminum oxide sandpaper remove any rough edges on the upper and lower portion of the tube and also scuff the inside the aluminum wrapper
- Remove the powder flux from the repair area by vigorously brushing the upper and lower portion of the tube with the round wire brush
- Clean the surfaces with the supplied alcohol pad in order to remove any dirt, debris, and oils. Allow the surfaces to air dry fully
- Combine two equal portions of the two part epoxy together
- Apply the epoxy with the application tool to the leak area and along the cleared fin section
- Place a small portion of remaining epoxy to the inside of the aluminum wrapper
- Place the aluminum wrapper over the leak area
- Crimp the aluminum wrapper with the needle-nose pliers
- With the use of a heat gun, apply equally distributed heat to the repaired area for roughly 15-20 minutes until epoxy changes from red to gold in color. Allow an additional 30 minutes for the epoxy to cure before leak checking the system
- Evacuate system down to 500 microns or less vacuum gauge pressure
- Recharge unit with refrigerant

SERVICES

Engineering

Kaltra specialists quickly and professionally help customers to choose the necessary type and configuration of the microchannel heat exchangers, calculate technical parameters, determine the best suitable type of aluminum alloys, connections, mountings options, as well as other characteristics in accordance with actual requirements and recommendations.

In accordance with the agreed parameters, Kaltra engineers promptly prepare the corresponding drawings, 3D models, and other necessary documentation. Drawings include complete details, dimensioning, tolerances, and heat exchanger specification.

Selection Software

MCHE selection software includes condenser, evaporator, heat pump, and water coils, making it a complete selection and calculation tool for refrigeration professionals.

The software provides selections and ratings for microchannel heat exchangers which enables the user to select the best-suited product based on several deciding parameters such as heat exchanger application, cooling capacity, refrigerant, evaporation and condensation temperatures, airflow and air temperature and other critical variables in refrigeration systems.

The latest version of MCH selection software is available for download at Kaltra website: <https://www.kaltra.com/software-inquiry>

Online information on Kaltra microchannel heat exchangers: <https://www.kaltra.com/microchannel-heat-exchangers>



Kaltra GmbH

Head office:

Viktualienmarkt 8
80331 Munich
Germany



+49(0)911 715 32021





info@kaltra.de



www.kaltra.com



Kaltra GmbH
Viktualienmarkt 8 • 80331 Munich • Germany
 info@kaltra.de
 +49(0)911 715 32021